

Catalogue

1.Spare part list and instruction steps

- Spare partslist.....①
- Integral construction①
- Instruction steps.....①

2.Use instruction

- Panel function.....②
- Button function instruction.....③

3.Function Parameters

- Main functions.....④
- Product parameters④

4.FAQ

- Notice.....⑤
- FAQ and solutions.....⑤

NO.4 FAQ



NOTICE

- ▲ Do not remove the machine when working.
- ▲ Do not stand in the front of shooting window when working.
- ▲ Do not touch the machine internal parts when working,avoid any danger.
- ▲ When cleaning up interior of the machine ,do not allow the minors operate the machine, avoid damage the machine or any danger.
- ▲ It is forbidden for minors to operate the machine.

Normal problems and solving methods

Problems	Cause reason	Solving methods
The machine do not work	①AC power connect failed ②Fuse is damaged ③Remote control no power	①Check the adapter if can Lights ②Change the fuse ③Change new battery
Weak ball shooting	①Ball flexibility is not enough ②The inner part is damaged	①Use Uniform pressure of volleyball ②If the above can not solve the problem please contact with the manufacturer or agents
The machine can not shoot balls	The shooting wheels has oil or water or it is not standard balls	①Take off the power,clear the water or oil.take out the stuck balls,take the fast speed to test ② If the above can not solve the problem please contact with the manufacturer or agents
The machine not shot normal	①Different specifications of the ball ②Shooting machine remove	①Choose the same standard volleyballs ②Brake the wheel