


二、 Use instruction

2.Introduction of remote control



2. Remote control operation

- (1) Fixed point: Press fixed point button.
Note: you can adjust the direction up,down,left and right.
- (2) Vertical line: First time:The vertical line circulation
Second time:High and low ball circulation
PS:you can adjust left or right direction
Press fixed point button to stop
- (3) Horizontal: once: The horizontal line circulation.
twice: Wide two line. thrice: Medium two line.
fourthly: Narrow two line. fifthly: Three line function.
Note: you can adjust direction up or down.
- (4) Random: Random balls in the court. Press fixed point button to stop.
- (5) Cross: First time:Left lowball & middle highball
Second time:Left highball & middle lowball
Third time:Middle lowball & right highball
Fourth time:Middle highball & right lowball
Fifth time:Left lowball & right highball
Sixth time:Left highball & right lowball
- (6) Self-program setting: ①Press more than 3 seconds to enter self-program,there is the blinking point on the screen.
②Press up,down,left,right to choose the point.
③When you choose the correct point then press self-program button to store it.
Note: There are 28 points you can choose to train.
- (7) Cancel program: ①Enter self-program.
②Press up,down,left,right to choose the point.
③When you choose the correct point then press program OFF button to cancel the point.
④Press program OFF more than 3 seconds,all points will be cancelled.
- (8) Topspin : Total six kinds of speed. Backspin: Total six kinds of speed.

Remark : ① Power switch key needs to be pressed for 3 seconds
② To enter self-program,"Program ON "needs to be pressed for 3 seconds

②

Special Note: This machine has a delay function.
Press the work key,it will start working after 15 seconds.

③